

DuraHook™ + DuraBoard™ P/N #DB-2-Kit Complete Storage System

(2 Boxes Make Up This Kit)

Instruction Sheet

1. Review Carton Contents: (2 Boxes Make Up This Kit)

- 2 Pcs. Polypropylene Pegboard 24" X 48" X 1/4" Thick
- 48 Pcs. Assortment DuraHook™ Locking Pegboard Hooks
- 60 Pcs. Lock Screws for hooks (short screws packaged separately)
- 4 Pcs. BinClips™ for hanging Plastic Bins
- 4 Pcs. Hanging Plastic Bins
- 16 Pcs. #12-2" long mounting screws
- 16 Pcs. #12 plastic wall anchors
- 16 Pcs. Metal wall mounts/spacers

2. Wall Mounting Instructions: (Inventory all components and Read all instructions thoroughly before installing.) Polypropylene pegboards can be mounted to walls in separate locations, side by side horizontally or above one another vertically.

- A) Determine the location or locations where you want to mount your new storage system.
- B) Determine if you want to mount boards (a.) side by side horizontally (b.) above or below one another, or (c.) in different locations from each other.
- C) Using one sheet of the Polypropylene Pegboard (DuraBoard™) determine the location and height you wish to mount your storage system.
- D) (Using diagram 1-1) Hold one sheet of Polypropylene Pegboard flat against the wall surface, use level to make sure board is level and square.
- E) (Using diagram 1-1) While still holding pegboard flat against wall level and using a pencil, make a circular trace inside of all (8) hole locations using diagram 1-1. (If planning to mount boards in totally separate locations go on to step (H))
- F) If you're planning to mount the second pegboard directly to the side or above or below the first: Hold the first pegboard flat against the wall while making sure all 8 traced holes are still aligned with appropriate holes in pegboard. Using a pencil, trace the outer edge of the board you're planning to mount the second board against.
- G) If mounting side by side or above or below one another: use the second board in your kit, align outer edge with the pencil mark created in step (F). **Do not cover up pencil mark with board.** Mark hole locations as called out in step (E).
- H) Using an electric drill with 5/16" drill bit, drill hole locations marked in step (E) and (G). Should any hole location fall inline with a wood wall stud, it will not be necessary to pre-drill.
- I) Gently insert plastic wall anchors into holes pre-drilled in step (H.) (You will not need to install plastic wall anchors where wall studs are located or when installing on solid wood surfaces. **Wall anchors will be required for all concrete walls.**)
- J) Using your first pegboard sheet Insert all eight (8) #12- 2" wood screws through the pegboard holes specified in diagram 1-2.
- K) Slip steel wall spacers over each screw from the back of the pegboard as shown in diagram 1-3.
- L) Insert each screw into its pre-installed wall anchor or assigned hole location. Using a #2 Phillips head screwdriver and starting from one of the top corner hole locations insert screws halfway. (This will leave you enough play/flexibility to insert each screw properly.)
- M) Once all 8 wood screws have been installed halfway, tighten all screws down to a point that all spacers are snug against wall surface. **(Always Avoid Over Tightening of Any Screw.)**

Repeat Instructions for installation of second pegboard panel

3. Hook Installation: (Using a hand held Philips head screwdriver)

- 1. Insert hooks panel engaging tab through first hole in pegboard.
- 2. Align hooks screw hole with second hole in pegboard.
- 3. Secure in place using small Philips head screws and hand held screwdriver **non-powered**. (Do not use 2" long wood screws.) **Do not over tighten screws used for mounting hooks.**

Note: All hooks can be mounted horizontally or vertically to store items and can be combined with one another to create storage solutions for heavier and odd shaped items and tools,

For questions about your DuraCenter™ kit or for installation help, please call Triton Products@ 440-248-5480 Mon- Fri. 8:00 AM to 5:00 PM EST or email www.customerservice@tritonproducts.com.

Warranty Information: All products are guaranteed free of defect for the life of the product. Return defective part (s) only, postage pre-paid along with copy of original purchase receipt to:

Triton Products
30700-D Carter Street
Solon, Ohio 44139
Phone 440-248-5480
Fax 440-248-5483

Liability: Triton Products liability is limited to 100% of the purchase price of the product. Check with your Retailer or Supplier for other great styles of hooks or storage solutions being offered by Triton Products or visit us @ www.tritonproducts.com

