



STRENGTH IN ORGANIZATION™

Thank you for your purchase!


If you have any problems with your order, please contact us first and we will make it right.

support@tritonproducts.com or call us at 440.248.5480

Checkout our new website! <http://tritonproducts.com>

1740 Storability® Installation Instructions

Package Contents:



Recommended Tools for Drywall Installation

- Drill
- 1/2" Drill Bit
- 1/8" Drill Bit
- #3 Philips Bit for Drill
- Level
- Pencil
- Stud Finder
- Tape Measure

Recommended Tools for Concrete Installation

- Hammer Drill
- Center Punch
- 5/16" Masonry Drill Bit
- 1/8" Masonry Drill Bit
- #3 Philips Bit for Drill
- Level
- Pencil
- Tape Measure


Assembled Dimensions - 66" W x 63" H x 16" D

Step 1. Locate the studs in the desired location for the top tracks. **Fig 1.** below shows you the 3 anchoring scenarios you will have with 16" on center wall construction.

Concrete installation

If you are installing on a concrete wall, you will only use **(A) Screws** with **(D) Anchors** for the entire installation. **Tip:** We highly recommend using a center punch followed by an 1/8" pilot hole before drilling the 5/16" holes for all 22 **(D) Anchors**. This will prevent your masonry bit from walking on the surface of the concrete, resulting in anchors not lining up properly with bracket holes. When drilling, make sure to hold the drill level so anchors fit tight. Continue to follow the instructions for dry wall installation.

Fig 1.



Step 2. Now that you have figured out your anchoring method, place the first top track **(G)** on the wall in the desired location and make sure it is level, now mark all 5 holes on the wall with a pencil.



Step 3. Drill the appropriate holes in all 5 locations. For studs **(A)** drill an 1/8" pilot hole, for anchors **(B & E)** drill a 1/2" hole.


Step 4. Insert **Screws (B)** in the locations of your top track where you will use drywall anchors **(E)**, now screw the drywall anchors on the end of the screws in the orientation shown in **Fig 1.** Make sure to run the screw all the way through the anchor bolt so they do not fall off inside the wall.

Step 5. Place the top track on the wall and push the dry wall anchors through the 1/2" holes, now start tightening the screws until the anchors slightly start to tighten up and stop, place your Level back on the top track and finish tightening the anchors. Now that your top track is level and the dry wall anchors are tight, screw in the **(A) Screws** in your stud locations.


Step 6. Place the second top track on the wall and line it up with the first one as shown below and repeat steps 2 through 5.




Step 7. Set the 3 top vertical rail sections into the top track as shown below.



Step 8. Now temporarily install the LocBoards **(L)** at the very top of the vertical rails on both sides as shown below (This will keep everything lined up easily for you) Make sure you are in the inside slots on the outer two vertical rails.




Step 9. Now make sure each vertical rail is level and mark holes **#1** and **#2** on all 3 vertical rails. Depending on your anchoring method, you can leave the LocBoards in while installing the vertical rails.



Step 10. Drill the appropriate holes in all 6 locations for the vertical rails. For studs **(A)** drill an 1/8" pilot hole, for anchors **(C & E)** drill a 1/2" hole.

Step 11. Fasten vertical rails to the wall making sure they stay level and seated properly in the top track.

Step 12. Slide vertical rail brackets **(K)** into the bottom of all 3 vertical rails and attach with screws **(J)** into hole **#3** in the orientation shown below. Do not tighten all the way just yet.



Step 13. Place the next set of vertical rails up with holes **#2** and **#3** positioned at the top and temporarily attach them with screw **(J)**, at this point you can move the 2 LocBoards down to these rails to keep things easily lined up if you like, otherwise, make sure each vertical rail is level with the top one and mark holes **#1** and **#2** on each vertical rail, now repeat steps 10 and 11 above. Depending on your anchoring method, you can leave the LocBoards in while installing the vertical rails.

Step 14. Now that all 6 of your vertical rails are fastened you can tighten up all 6 **(J)** screws.

Step 15. Relocate the LocBoards to your desired location if you left them up during installation.

Step 16. Attach wire shelf brackets (I) on the ends of each wire shelf (H) as shown in Fig 5. and Fig 6. below.







Fig 5.




Fig 6.



Step 17. Attach steel shelf brackets (N) on the ends of the steel shelf (M) as shown below. The edge of the shelf with 2 holes is the back side of the shelf.




Step 18. Install shelves in desired locations on vertical rails as shown below.




Step 19. Install the 2 combination rails (Q and R) in your desired location in the same fashion as the shelf brackets from the previous step. Now add the hooks in your desired location on the combination rail securing them with (S) screws, now install the bins by sliding them down at the top of the combination rail.



Step 20. Attach brackets (P) to wire basket (O) and hang basket in desired location.



Step 21. Install LocHooks (T) in your desired locations securing them with LocScrews (U)



Congratulations on installing your Triton Products Storability 1740! We hope you really enjoy it!

