



STRENGTH IN ORGANIZATION™

Thank you for your purchase!


If you have any problems with your order, please contact us first and we will make it right.

support@tritonproducts.com or call us at 440.248.5480

Checkout our new website! <http://tritonproducts.com>

### 1785 Storability® Installation Instructions

#### Package Contents:



### Recommended Tools for Drywall Installation

- Drill
- 1/2" Drill Bit
- 1/8" Drill Bit
- #3 Philips Bit for Drill
- Level
- Pencil
- Stud Finder
- Tape Measure

### Recommended Tools for Concrete Installation

- Hammer Drill
- Center Punch
- 5/16" Masonry Drill Bit
- 1/8" Masonry Drill Bit
- #3 Philips Bit for Drill
- Level
- Pencil
- Tape Measure


### **Assembled Dimensions - 33" W x 63" H x 16" D**

**Step 1.** Locate the studs in the desired location for the top track. **Fig 1.** below shows you the 3 anchoring scenarios you will have with 16" on center wall construction.

### **Concrete installation**

If you are installing on a concrete wall, you will only use **(A) Screws** with **(D) Anchors** for the entire installation. **Tip:** We highly recommend using a center punch followed by an 1/8" pilot hole before drilling the 5/16" holes for all 13 **(D) Anchors**. This will prevent your masonry bit from walking on the surface of the concrete, resulting in anchors not lining up properly with bracket holes. When drilling, make sure to hold the drill level so anchors fit tight. Continue to follow the instructions for dry wall installation.

**Fig 1.**



**Step 2.** Now that you have figured out your anchoring method, place the top track **(G)** on the wall in the desired location and make sure it is level, now mark all 5 holes on the wall with a pencil.



**Step 3.** Drill the appropriate holes in all 5 locations. For studs **(A)** drill an 1/8" pilot hole, for anchors **(B & E)** drill a 1/2" hole.

**Step 4.** Insert **Screws (B)** in the locations of your top track where you will use drywall anchors **(E)**, now screw on the drywall anchors on the end of the screws in the orientation shown in **Fig 1**. Make sure to run the screw all the way through the anchor bolt so they do not fall off inside the wall.

**Step 5.** Place the top track on the wall and push the dry wall anchors through the 1/2" holes, now start tightening the screws until the anchors slightly start to tighten up and stop, place your Level back on the top track and finish tightening the anchors. Now that your top track is level and the dry wall anchors are tight, screw in the **(A) Screws** in your stud locations.


**Step 6.** Place vertical rails **(F)** at the very end of each side of the top track as shown in **Fig 2.** **Tip!** Insert the LocBoard **(L)** at the very top of the vertical rails as shown in **Fig 5.** below to help keep rails lined up properly. Still make sure the vertical rails are level as shown in **Fig 3.** and mark holes **#1** and **#2** on both vertical rails as shown in **Fig. 4** Depending on your anchoring method, you can leave the LocBoard in while you secure the vertical rails down.




**Fig 2.**



**Fig 3.**



**Fig 4.**




**Fig 5.**

**Step 7.** Drill the appropriate holes in all 4 locations for the vertical rails. For studs **(A)** drill an 1/8" pilot hole, for anchors **(C & E)** drill a 1/2" hole.

**Step 8.** Fasten vertical rails to the wall making sure they stay level and seated properly in the top track.

**Step 9.** Slide vertical rail brackets (**K**) into the bottom of both vertical rails and attach with screws (**J**) in the orientation shown below. Do not tighten all the way just yet.



**Step 10.** Place the next set of vertical rails up with holes #2 and #3 positioned at the top and temporarily attach them with screw (**J**), at this point you can move the LocBoard down to these rails to keep things easily lined up if you like, otherwise, make sure each vertical rail is level with the top one and mark holes #1 and #2 on each vertical rail, now repeat steps 7 and 8 above. Depending on your anchoring method, you can leave the LocBoard in while installing the vertical rails.


**Step 11.** Now that all 4 of your vertical rails are fastened, you can tighten up all 4 (**J**) screws.

**Step 12.** Relocate the LocBoard to your desired location if you left it up during installation.

**Step 13.** Attach wire shelf brackets (**I**) on the ends of the wire shelf (**H**) as shown in **Fig 5.** and **Fig 6.** below.




**Fig 5.**




**Fig 6.**


**Step 14.** Install shelf in desired location on the vertical rails as shown below.




**Step 15.** Install the combination rail (O) in your desired location in the same fashion as the shelf brackets from the previous step. Now add the hooks in your desired location on the combination rail securing them with (S) screws, now install the bins by sliding them down at the top of the combination rail.



**Step 16.** Attach brackets (N) to the wire basket (M) and hang basket in desired location.



**Step 17.** Install LocHooks (Q) in your desired locations securing them with LocScrews (U)



Congratulations on installing your Triton Products 1740! We hope you really enjoy it!

