

1700 Storability® 33"L x 1-3/4"H Top Track Wall Frame

Read all instructions completely before installing. Should you have any questions about your installation, please call Customer Service at 440-248-5480. Missing and damaged parts must be reported within 5 days from receipt of delivery.

Tools needed for this installation (Not Supplied with Kit)

Level - Pencil or marker - Phillips head screw driver - Electric drill - 1/2" Standard drill bit for hollow wall installation - 1/16" Standard drill bit for stud wall Installation - 5/16" Masonry bit for concrete block Installation - Tape measure - Safety glasses All mounting hardware included for hollow and concrete block wall installations

Parts Listing

P/N#	Quantity	Description
1700	1	Top Track Sections
	5	2-1/2" Toggle Bolts
	5	White Plastic Wall Anchors
	5	2-1/4" Wood Screws
	5	Toggle Bolt Expanders
		Mounting Hardware Included

Drill Diameter Listing: Drill diameter sizing for: Hollow wall installations; Use 1/2" standard drill bit
 Drill diameter sizing for: Concrete wall installations; Use 5/16" masonry drill bit
 Drill diameter sizing For: Wood stud wall Installations; Use 1/16" standard drill bit for pilot holes

Preparation for Top Track Installation: (Image A-1)

1. If installing in a corner, leave 1" space between side wall and top track.
2. Determine the maximum height of storage you would like available above your system. (See Fig. A-1). For an 8 foot ceiling; 78" off the floor leaves 18" of storage above and 81" off the floor leaves 15" storage above.
3. Using a tape measure, mark your desired height off the floor with a 4" long pencil mark.
4. (Refer to Fig. A-1) Using a level, align top of top track with your pencil mark in step 3. With top track level, mark the center of each holes location on your wall. (Note: Before starting to drill holes; always make sure all screw hole locations do not fall in line with electrical wires, Duct work or plumbing inside of your wall. If a potential problem exists, reposition and re-mark screw hole locations.)
5. (Fig. A-2) Drill hole locations marked using the correct drill bit sizing and type listed above. Should you come in contact with wood studs, stop and mark the hole with X and after drilling all other holes come back and drill holes marked with an X using a 1/16" bit for pilot hole for wood screws.

Attachment of Top Track to Wall Surface: (Fig. A-3)

6. For hollow walls; (Fig. A-3) Use 2-1/2" long toggle bolts with expanders. Make sure to insert all toggle bolts through top track and attach all toggle bolt expanders, insert toggle bolts with expanders into holes in wall before starting step 9.
7. For concrete walls; use white plastic wall anchors and 2-1/4" long wood screws. Install all plastic wall anchors in each pre-drilled hole location before starting step 9.
8. For wood studs; use 2-1/4" long wood screws. Always install wood screws last and there will be no need to use plastic wall anchors.
9. Using a level and holding top track in place tighten one of the end toggle bolts or wood screws until snug. (Allow for a little track movement.)
10. Making sure top track is level, tighten toggle bolt or install wood screw on the opposite end until fully secure and then re-tighten 1st bolt or wood screw installed while still level.
11. Install and fully tighten all remaining toggle bolts and wood screws.

Please contact our Customer Service Division with any questions at:
 30700 D Carter Street · Solon, OH 44139 · (P) 440.248.5480 · support@tritonproducts.com

For a full line of products visit www.tritonproducts.com

